


Landscape Contractors Tailgate Meeting Series Grass Trimmer

What Can Happen! Improperly using a grass trimmer can result in severe cuts and lacerations, burns from hot machine parts, eye injuries, and strains and sprains.

ALWAYS

- Read and follow the operator's manual and use the grass trimmer according to the manufacturer's instructions. If you have questions about the equipment, ask your supervisor.
- Equip yourself with long pants, safety glasses with face shield, hearing protection, leather work shoes or boots with leather uppers and heavy duty, non-slip gloves.
- Make sure shields, guards, and other safety devices are in place and working properly.
- Inspect the unit before use and replace damaged parts, or remove the damaged equipment from use until repaired.
- Start the equipment on firm ground or other solid surface in an open area.
- Carefully inspect the area before starting the unit and remove stones, glass, metal and debris.
- Use the trimmer on level ground only.
- Stop the engine before cleaning out clogged or stuck material.



STOP! THINK!


- DO NOT** raise trimmers above waist level when trimming.
- DO NOT** leave running tool unattended.
- DO NOT** wear short pants or short sleeve clothing.
- DO NOT** overreach. Keep proper footing and balance at all times.
- DO NOT** repair damaged attachments - throw them out.
- DO NOT** touch a hot muffler or cylinder. Note: when turned off, they remain hot for a short time.

Contratistas de Jardinería Reuniones de Seguridad Cortadoras de Pasto

Lo que puede pasar! El uso inapropiado de una cortadora de césped/pasto puede resultar en laceraciones y cortadas severas, quemaduras por las partes calientes de la máquina, lesiones en los ojos, torceduras y esguinces.

SIEMPRE

- Lea y siga las instrucciones del manual del operador y use la cortadora de césped/pasto de acuerdo a las instrucciones de fábrica. Si tiene preguntas acerca del equipo, pregúntele a su supervisor.
- Equípese con pantalones largos, gafas protectoras con cubierta para la cara, protectores para los oídos, botas o zapatos de piel y para trabajo pesado, guantes anti-derrapantes.
- Asegúrese que las cubiertas, protectores y otros mecanismos de seguridad estén en su lugar y trabajando apropiadamente.
- Inspeccionar la unidad antes de usarla y reemplazar las partes dañadas o retirar el equipo de uso hasta que sea reparado.
- Encender el equipo en un área abierta en tierra firme u otra superficie sólida.
- Inspeccionar cuidadosamente el área antes de encender la unidad y remover piedras, vidrio, metal y escombros.
- Usar la cortadora en superficie plana solamente.
- Apagar la máquina antes de limpiar o quitar el material atascado ó atorado.



ALTO! PIENSE!

NO levantar la cortadora arriba del nivel de la cintura cuando este cortando.

NO dejar una herramienta prendida sin atender.

NO usar pantalones cortos o ropa de manga corta.

NO se estire de mas. Mantenga su balance y posición apropiada en todo momento.

NO reparar accesorios dañados – tirélos a la basura.

NO toque el mofle o cilindro caliente. Aviso: cuando se apaga el motor, continúa estando caliente por un corto tiempo.